



General characteristics

Pneumax is introducing the latest evolution of the 2400 series, new base mounted line including electrical connection into the manifold.

 $Many \, technical \, features \, make \, the \, new \, product \, interesting:$

- Flow rate of 1000 NI/min
- Low consumption coils placed all in one side of the valve
- Quick mounting of the valve to the base using just one screw
- Quick connection of the bases thanks to 180 degree rotating pins
- Possibility to use different pressures along the manifold (including vacuum)
- IP65 environmental protection

- Electrical connection directly integrated into the base, 32 electrical signals available (can be used to build up a manifold of 32 monostable valves, 16 bistable valves or any combination within that limit).

The electrical connection is made via 37 pin SUB-D connector.

Possibility to integrate with Field Bus modules (all the most common protocols will be available).

Possibility to connect input modules (even on the base that does not have the Field Bus module.

Large use of technopolymer material reduces the overall weight of the manifold.

Main characteristics

Integrated and optimized electrical connection system

IP65 protection degree

Only one 19mm size

Electrical line connections on one side

Monostable and bistable solenoid valves with the same size dimensions

Easy and fast manifold assembly

Construction characteristics

Body	Technopolymer
Operators	Technopolymer
Spools	Nikel plated steel / Technopolymer
Spacers	Technopolymer
Seals	NBR
Piston seals	NBR
Springs	AISI 302 stainless steel
Pistons	Technopolymer

Functions

5/2 MONOST. SOL. SPRING
5/2 MONOST. SOL. DIFFERENTIAL
5/2 BISTABLE SOL. SOL.
5/3 CC SOL. SOL.
2x3/2 NC-NC (= 5/3 OC) SOL. SOL.
2x3/2 NO-NO (= 5/3 PC) SOL. SOL.
2x3/2 NC-NO SOL. SOL.

Technical characteristics

Voltago	24 VDC ±10% PNP
Voltage	24 VDC ± 10% PNP
Pilot consuption	1,2 Watt
Valve working pressure [1]	from vacuum to 10 bar max.
Pilot working pressure [12-14]	From 3 to 7 bar max.
Operating temperature	-5°C+50°C
Protection degree	lp65
Life (standard operating conditions)	50.000.000
Fluid	Filtered and lubricated air or not
	(if lubricated air, the lubrication must be continuous)

Solenoid valves "OPTYMA32-F"

Series 2500







Operational	Fluid	Pressure range (bar) (bar) pilots 12-14		Temperature °C		Flow rate at 6 bar with $\Delta p=1$ (NI/min)	*Activation time (ms)	*Deactivation time (ms)
characteristic	Filtered and lubri- cated air or not	From vacuum to 10	3 - 7 bar	Min. -5°C	Max. +50°C	700 NI/min	T.R.E. 15 ms	25







Series 2500





The electrical connection is achieved by a 37 pin connector and can manage up to 32 solenoid pilots.

It is also possible use a 25 sub-D pin connector and, in this case, it is possible to manage a maximum of 22 outputs.

The management and distribution of the electrical signals between each valve is obtained thanks to an electrical connector which receives the signals from the previous module, uses one, two or none depending on the type, and carries forward to the next module the remaining.

Bistable valves, 5/3 and 2x3/2 valves which have two solenoid pilots built in, use two signals; the first is directed to the pilot side 14 the second to the pilot side 12. Modular bases can be fitted with two type of electrical connector: the monostable version uses only one signal (connected to the pilot side 14) and carries forward the remaining, the bistable version which always uses two signals.

This solution allows the modification of the manifold (replacement of monostable valves without bistable for example) without having to reset the PLC output layout.

On other hand this solution limits the maximum number of valves to 16 when it is used a 37 pin connector or 11 when it is used a 25 pin connector.

Intermediate supply/exhaust module uses an electrical connector directly forwarding signals to the next one without any kind of modification.

This allows the use of intermediate modules in any position of the manifold.

All the electrical signals that have not been used on the manifold can be used placing at the end of the manifold the end plate complete with the 25 sub-D female connector.

The number of available signals depends of the connector used to the type of the left end plate and by the total signals used along the manifold:

37 pin connector	nr of output = $32 - (total of used signals)$
25 pin connector	nr of output = $22 - (total of used signals)$

Following we show some examples of possible combination and the relative pin assignment.







1 - 22 = Solenoid valves signals 23 - 24 = GND 25 = Through line



Series 2500





PIN	1	=	PII	ОТ	14	EV	POS	.1
PIN	2	=	PII	_OT	12	EV	POS	.1
PIN	3	=	PII	_OT	14	EV	POS	.2
PIN	4	=	PII	_OT	14	EV	POS	.3
PIN	5	=	PII	_OT	14	EV	POS	.4
PIN	6	=	PII	_OT	12	EV	POS	.4
PIN	7	=	PII	_OT	14	EV	POS	.5
PIN	8	=	PII	_OT	14	EV	POS	.7
PIN	9	=	PII	_OT	14	EV	POS	.8
PIN	10	=	PII	_OT	14	EV	POS	.9
PIN	11	=	PII	_OT	14	EV	POS	.10
PIN	12	=	PII	_OT	14	EV	POS	.11
PIN	13	=	PII	_OT	12	EV	POS	.11
PIN	14	=	PII	_OT	14	EV	POS	.12
PIN	15	=	PII	_OT	12	EV	POS	.12

37 PIN Connector correspondence for manifold mounted on bases for bistable valves

	1 2	3	5	7 8	9 10		12	13	15 16	18	19 ₂₀	9 ₂₂	
										Constants Billing of the			
Anna anna 1974 - Ionain Millionna Anna Stationna Millionna	11												and a second sec
100		0	0		0		0	0	8	•			-
.8			•		•	00	•			•			8
						0							6.
		-	T				Π	T	Π	Π	11		
POS.	1	2	3	4	5	6	7	8	9	10	11	12	

PIN 1	= PILOT 14 EV I	POS.1
PIN 2	= PILOT 12 EV I	POS.1
PIN 3	= PILOT 14 EV I	POS.2
PIN 4	= NOT CONNEG	CTED
PIN 5	= PILOT 14 EV I	POS.3
PIN 6	= NOT CONNE	CTED
PIN 7	= PILOT 14 EV F	POS.4
PIN 8	= PILOT 12 EV I	POS.4
PIN 9	= PILOT 14 EV F	POS.5
PIN 10	= NOT CONNE	CTED
PIN 11	= PILOT 14 EV I	POS.7
PIN 12	= NOT CONNE	CTED
PIN 13	= PILOT 14 EV I	POS.8
PIN 14	= NOT CONNE	CTED
PIN 15	= PILOT 14 EV F	POS.9
PIN 16	= NOT CONNE	CTED
PIN 17	= PILOT 14 EV F	POS.10
PIN 18	= NOT CONNEG	CTED
PIN 19	= PILOT 14 EV F	POS.11
PIN 20	= PILOT 12 EV F	POS.11
PIN 21	= PILOT 14 EV F	POS.12
PIN 22	= PILOT 12 EV I	POS.12

37 PIN Connector correspondence for manifold for 32 position manifold with monostable valves on base

25 PIN Connector correspondence for manifold for 22 position manifold with monostable valves on base







Ordering code

2530.08F

General :

Using the 2530.03.25P output terminal it is possible to make any electrical signals not used by valves available on a 25 sub-D female connector at the right end of the manifold.

It is possible to then join a multi-core cable to link to the next manifold, or connect directly to one or two I/O modules.

The I/O modules can accept input or output signals, depending upon what is connected.

Please note: If the manifold is connected by a multi-core connection, each connection can be used as either an input or an output, while if the manifold is connected to a serial node the connections can only be used as an output.

It is possible to connect the manifold to up to two I/O modules.

Each I/O module includes 8 diagnostic LEDs which indicate the presence of an Input / Output signal for each connector.

Please note: For an LED to function, a signal of at least +15VDC must be present on pin 4 • of the connector. If this signal is lower, the LED will not light, this does not compromise the normal Input/Output function of the unit.

Overall dimensions and I/O layout :



Input features:

Each connection can accept either two wire (switches, magnetic switches, pressure switches, etc.) or three wire connections (photocells, electronic end of stroke sensors, etc.) If +24VDC is required on at Pin 1 of each connector, it is possible to provide this via the through-line pin of the multi-pole connector.

I.E :

Pin 25 of the 25 pin multi-pole connector (code 2530.02.25P or 2530.12.25P) Pin 36-37 of the 37 pin multi-pole connector (code 2530.02.37P or 2530.12.37P)

02020

Output features:



Attention: The output connections are not protected against short-circuit. Please pay attention when wiring (avoid Pin 4 being connected to Pin 3 or Pin 1).

		Model	2530.08F				
		Case	Reinforced technopolymer				
		I/O Connector	M8 connector 3 poles female (IEC 60947-5-2)				
S	S	PIN1 voltage	by the user				
	0	(connector used as Input)					
= '		PIN 4 voltage diagnosis	Green LED				
ral	Ť	Node consumption (Outlets excluded)	7mA per each LED with 24 VDC signal				
ē	ē	Outlets voltage	+23,3 VDC (serial) /by the user (multipolar)				
Genei	cte	Input voltage	Depend by the using				
ŭ,	ອ,	Maximum outlet current	100 mA (serial) / 400 mA (multipolar)				
	hai	Maximum Input/Output	8 per module				
	с,	Multiconnector max. Current	100 mA				
	0	Connections to manifold	Direct connection to 25 poles connector				
		Maximum n. of moduls	2				
		Protection degree	IP65 when assembled				
		Ambient temperature	from -0° to +50° C				

2

Solenoid valves "OPTYMA32-F" Accessories - Module 8 Imputs

PIN PIN PIN 1 PIN 8 PIN 1 PIN 1

Connection modes:

Control via fieldbus

PIN DESCRIPTIO

THROUGH LINE

SIGNAL

GND

A) Control via multi-pole : M8 connector used as Input:

B)

Control via multi-pole connection

multi-pole connector pin.

SUB-D TYPE 37 POLE MALE CONNECTOR

PIN 16



Multi-pole connector pin 12-34-567 37 poles Connector are possible Multi-pole (12)(13)(14)(15) 20(21(22)23 connector Module 1 Module 2 pin Attention : Optyma 32-F solenoid valve manifolds permit up to 22 electrical signals that are not used by manifolds to be made available: these signals can be managed by another manifold and / or by I/O modules. The I/O module will manage these unused signals. Connections that are not managing useful signals will remain unconnected. 1 2-3 4-5 6 7 22 Signals : 8 9 10 11 16 17 18 19 1234-5 6 7-89-10 11 12 (13) (14) (15) (16) (21) 22 23 24 37 poles Maximum Connettor 22 Signals 01010 01010 (7) (8) (9) 20 25 26 27 Not Connected Multi-pole Outlet signals 12 13 14 15 20 21 22 connector from manifold Module 1 Module 2 pin

Please note: this example considers a 37 pin multi-pole connector. The same configuration managed by a 25 pin multi-pole connector will stop at number 22 of multi-pole connector and at number 17 of the manifold. 22 17

Attention:

Signal Not connected

Through line Connected

GND Connected



Please note: Optyma 32-F solenoid valve manifolds manage up to 32 signals. If the manifold uses more than 24 signals the I/O module will manage only the remainder. Connections that are not managing useful signals will remain unconnected.



B) Control via fieldbus:

With this kind of control the I/O module can only be used as an output. Pin 1 of each connector is not connected. The output voltage will be 0.7V lower than that applied to Pin 4 of the connector.

The maximum output current for each output is 100mA. Te correspondence between control byte and each single output depends on how many electrical signals are used by the manifold and by the relative position of the I/O module.



2



Specifications may be subject to change without prior notice



Series 2500





NOTE:

While configuring the manifold always be careful that the maximum number of electrical signals available is: 32 when an input 37 poles endplate is used. 22 when an input 25 poles endplate is used.

The use of monostable valve mounted on a base type 2 (2 electrical signals occupied) causes the loss of one electric signal.

In this case the monostable valve can be replaced by a bistable valve. The diaphragms plugs are used to intercept the conduits 1,3 & 5 of the base. If it is necessary to interrupt more than one conduit in the same time then put in line the letters which identifies the position (for exemple : regarding the 3 & 5 conduits, put the Y & Z letters).

Should one or more conduits be cut more than one time it is necessary to add the relevant intermediate Supply/Exhaust module.